



## **ZT Conversion Kit Installation Instructions**

The following instructions will allow you to install the ZT grip onto your Akron nozzle. Different Akron nozzles use different ZT grips, so make sure you have the proper ZT for your Akron nozzle.

To prepare your nozzle to install the ZT:

1. First remove the swivel assembly from your nozzle. To do this you must remove the set screw at the inlet end of the shutoff body with an Allen wrench.
2. Now unthread the swivel assembly by placing the proper swivel adapter tool into the notches in the swivel adapter waterway. The swivel adapter tool may be found in the Style 9200 tool kit.
3. Once the swivel assembly is removed, remove the seat and O-ring from the swivel adapter. These will be placed in the ZT swivel adapter.

To install the ZT:

1. Place the seat and O-Ring into the ZT swivel adapter (1).
2. Thread the ZT assembly (2) into the shutoff body of the nozzle. Tighten until the shutoff handle operates properly.
3. Re-install the set screw into the shutoff body. You may need to drill a slight dimple into the swivel adapter through the set screw hole in order for the set screw to go down flush with the shutoff body.
4. Loosen the set screw (3) at the outlet end of the ZT, just enough to rotate the ZT assembly into the proper position. Once into position, tighten the set screw tight enough to lock the ZT in place.
5. Test the nozzle to make sure there are no leaks and the nozzle operates properly.

