



Assembly Notes

 Use Loctite 222 or Permabond LM113

 Use Loctite 277 or Permabond HH120



**STYLE 765, 766, 768, 775
776, 777, 785
FOAM TUBE
TECHNICAL SERVICE PARTS LIST**

ITEM NO.	DESCRIPTION	PART NUMBER	QUANTITY						
			765	766	768	775	776	777	785
1	Bumper	101867	1	1	1	1	1	1	1
2	Tube Etched	124209			1				
2	Tube Etched	124227	1						
2	Tube Etched	124223		1					
2	Tube Etched	124223						1	
2	Tube Etched	124224				1			
2	Tube Etched	124229					1		
2	Tube Etched	124226							1
4	Base	123852	1						
4	Base	123850		1					
4	Base	123853						1	
4	Base	119952			1				
4	Base	123847				1			
4	Base	123849					1		
4	Base	123851							1
5	Soc. Hd. Cap Screw	767127	1	1	1	1	1	1	1
6	Locking Cam	101868	1	1	1	1	1	1	1
7	Detent Ball	703050	1	1	1	1	1	1	1
8	Detent Spring	768023	1	1	1	1	1	1	1
9	Screw	765182	4	4	4	4	4	4	4
10	O-Ring	757254	1	1	1	1	1	1	1

Operating Instructions

1. Turn the Locking Cam round side out.
2. Position the unit at a 45 degree angle to the bumper of the nozzle with the two ears on the Foam Tube base under the lip and between the lugs of the bumper.
3. Push the base over the bumper of the nozzle.
4. Rotate the Locking Cam into the fully locked position.

Warning: Fully engage Locking Cam before operating

- 125 GPM maximum flow
- 100 PSI maximum nozzle pressure
- Do not operate in wide fog



Tested.. Proven.. Trusted.

ISO 9001 REGISTERED COMPANY

PHONE: 330.264.5678 or 800.228.1161 | FAX: 330.264.2944 or 800.531.7335 | akronbrass.com

REVISED: 9/15

WARRANTY AND DISCLAIMER: We warrant Akron Brass products for a period of five (5) years after purchase against defects in materials or workmanship. Akron Brass will repair or replace product which fails to satisfy this warranty. Repair or replacement shall be at the discretion of Akron Brass. Products must be promptly returned to Akron Brass for warranty service.

We will not be responsible for: wear and tear; any improper installation, use, maintenance or storage; negligence of the owner or user; repair or modification after delivery; damage; failure to follow our instructions or recommendations; or anything else beyond our control. WE MAKE NO WARRANTIES, EXPRESS OR IMPLIED, OTHER THAN THOSE INCLUDED IN THIS WARRANTY STATEMENT, AND WE DISCLAIM ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR ANY PARTICULAR PURPOSE. Further, we will not be responsible for any consequential, incidental or indirect damages (including, but not limited to, any loss of profits) from any cause whatsoever. No person has authority to change this warranty.

© Akron Brass Company. 2014 All rights reserved. No portion of this can be reproduced without the express written consent of Akron Brass Company.