



## STYLE 4463 RAMPAGE NOZZLE w/ Hydraulic Pattern Actuator OPERATING INSTRUCTIONS

The following is intended to provide the basic instructions for operating a Style 4463 Rampage Nozzle with Hydraulic Pattern Actuator. Read and understand these operating instructions before use.

### PRODUCT RATINGS

Flow:	500 -1000 gpm @ 100 psi/7 bar
Maximum Pressure:	200 psi/14 bar
Hydraulic Pressure/Flow Requirements:	1/8 GPM @ 500 PSI Maximum

### PRODUCT WARNINGS

- WARNING: Charge all lines slowly to facilitate a controlled water pressure build-up during start-up. Open and close slowly. Rapid opening will produce a sudden thrust. Rapid opening and closing can cause water hammer. Have your monitor properly supported to control the reaction force created by the stream.
- WARNING: At pressures below that indicated on the label, the nozzle will have reduced flow and reach. Be sure you have enough flow and pressure for the situation (See IFSTA and NFPA manuals for guidelines).
- WARNING: Ensure the nozzle is aimed in a direction that is safe, prior to flowing.
- WARNING: Do not use the nozzle as a forcible entry tool. Doing so may damage it or make it inoperable.
- WARNING: Ensure the thread on the nozzle swivel is matched to the thread on the monitor.

### PRODUCT CAUTIONS

- CAUTION: If any tags or bands on the nozzle are worn or damaged and cannot be easily read, they should be replaced.
- CAUTION: For use with fresh water or standard fire fighting foams only. Not recommended for use with salt water. After use with foam or salt water, flush with fresh water.
- CAUTION: Do not over tighten the nozzle onto the monitor.
- CAUTION: The nozzle is configured for optimum performance. Do not alter in any manner.
- CAUTION: Your nozzle should be inspected prior and after each use, to ensure it is in good operating condition. Periodically, an unanticipated incident may occur where the nozzle is used in a manner that is inconsistent with standard operating practices and those listed in IFSTA. A partial list of potential misuses follows:
- Operating above maximum rated pressure and flow.
  - Not draining, and allowing water to freeze inside the nozzle.
  - Dropping the nozzle from a height where damage is incurred.
  - Prolonged exposure to temperatures above +140 degrees F, or below -40 degrees F,
  - Operating in an extremely corrosive environment.
  - Other misuse that might be unique to your specific fire fighting environment.

There are many “tell tale” signs that indicate nozzle repair is in order, such as:

- Controls that are either inoperable or difficult to operate.
- Excessive wear.
- Poor discharge performance.
- Water leaks.

If any of the above situations are encountered, the nozzle should be taken out of service and repaired, plus tested by qualified nozzle technicians, prior to placing it back in service.

## OPERATING INSTRUCTIONS

- To change the 750 gpm flow rate, remove the baffle head and .118” thick spacer and install the 1000 gpm spacer (.218” thick) or use no spacer for 500 gpm.
- To flush the nozzle hydraulically operate the pattern sleeve towards the fog position until it stops. This gives you the maximum orifice for clearing small debris.

## MAINTENANCE

- Under normal conditions, periodically flushing the nozzle with clean water and cleaning grit and dirt from around exterior moving parts will allow the nozzle to operate as designed.
- Periodically (at least annually), lubricate the pattern sleeve with Low-Temp Lubriplate by using the grease fitting on the side of the pattern sleeve.
- Over time the O-Rings may need to be replaced. This can be accomplished by purchasing the appropriate O Rings shown on the service parts list. Use qualified maintenance mechanics or return the nozzle to Akron Brass for repair.



**Tested... Proven... Trusted.**

ISO 9001 REGISTERED COMPANY

PHONE: 330.264.5678 or 800.228.1161 | FAX: 330.264.2944 or 800.531.7335 | [akronbrass.com](http://akronbrass.com)

REVISED: 8/08

WARRANTY AND DISCLAIMER: We warrant Akron Brass products for a period of five (5) years after purchase against defects in materials or workmanship. Akron Brass will repair or replace product which fails to satisfy this warranty. Repair or replacement shall be at the discretion of Akron Brass. Products must be promptly returned to Akron Brass for warranty service.

We will not be responsible for: wear and tear; any improper installation, use, maintenance or storage; negligence of the owner or user; repair or modification after delivery; damage; failure to follow our instructions or recommendations; or anything else beyond our control. WE MAKE NO WARRANTIES, EXPRESS OR IMPLIED, OTHER THAN THOSE INCLUDED IN THIS WARRANTY STATEMENT, AND WE DISCLAIM ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR ANY PARTICULAR PURPOSE. Further, we will not be responsible for any consequential, incidental or indirect damages (including, but not limited to, any loss of profits) from any cause whatsoever. No person has authority to change this warranty.

© Akron Brass Company, 2000 All rights reserved. No portion of this can be reproduced without the express written consent of Akron Brass Company.